
# IQOS ILUMA

ONE

#### IQOS ILUMA ONE™



IQOS ILUMA™ is compatible only with SMARTCORE STICKS™

# SUPPORT AND SERVICES

customer support and additional services for IQOS users, please visit

www.iqos.com/services

# FEATURES AND SETTINGS

You can modify your IQOS experience according to your preferences with the IQOS App\*.

Please register by scanning QR code or log in on www.iqos.com/iluma and follow the instructions.


 IQOS app may not be available in your country.

# **Getting Started**



#### TURN ON

Press and hold Button for 4 seconds, then release; Status Lights will turn on slowly.



#### CHARGE


Before first use, fully charge your IQOS ILUMA ONE™ with Power Adaptor and Charging Cable.

(approx. 90 min)

# How to use your IQOS ILUMA ONE™



OPEN Slide to open.



1. INSERT SMARTCORE STICK™


Insert the SMARTCORE STICK™ to the line on filter with filter facing outside.



#### 2. START HEATING

Press Button for at least 1 second until IQOS ILUMA ONE™ vibrates and Status Light(s) pulse(s).


Keep SMARTCORE STICK™ in position during the preheating.



#### 3. BEGIN USE

Start using once IQOS ILUMA ONE™ vibrates and Status Light(s) stay fixed.

# How to use your IQOS ILUMA ONE™




EXPERIENCE COUNTDOWN

During use, Status Light(s) indicate the remaining time.




4. NEARLY COMPLETE

To signal the last 30 seconds or last 2 puffs, IQOS ILUMA ONE™ will vibrate with one Light pulsing white.



5. REMOVE SMARTCORE STICK™

Remove used SMARTCORE STICK™ and dispose as per Safety Warnings and Instructions.



6. CLOSE Slide to close

# **Quick Tips**




#### **BATTERY STATUS**

Short press Button, Status Lights will turn on to indicate battery level.




#### LIGHT BLINKS YELLOW

Battery depleted, need to charge.



#### **AUTOSTOP**


During use, the experience will stop if the specifically designed tobacco stick is moved, or removed from the device.



#### LIGHTS BLINK WHITE TWICE

IQOS ILUMA ONE™ is outside operating temperature range (0°C~40°C).


# **Quick Tips**



LIGHT BLINKS RED

Reset IQOS ILUMA ONE™.

If red light blinking persists, contact Customer Care.



TO RESET
Press Button for 10 seconds
then release. All Status
Lights will turn OFF, and turn
ON, to confirm a RESET.